

24/7 Customer Support



support@techmatte.com

www.techmatte.com

STAY CONNECTED











(OneTouch)

Installation Guide


Scan Me



or visit

www.TechMatte.com/install/GLS-NIN

1 Detach both Joy Con from your Switch.



2 Begin by cleaning the screen with the Wet Wipe and the Microfiber Cleaning cloth. Remove any dust with the dust removal sticker.



Remove any case from the Switch. Place the Easy Installation Tray on the Switch.



Peel off the first mask film from the Screen Protector, exposing the adhesive surface.



Using the Easy Installation Tray as a guide, line up the bottom of the protector with one end of the Installation Tray. Slowly place the protector onto the Switch.



6 Using your index finger, swipe down the middle of the screen protector so that the protector will adhere itself to your Switch.



Remove the Installation Tray, and squeeze out any bubbles under the screen protector. Press around the edges to ensure the protector is sealed.



Re-attach Joy Con and enjoy your Switch.

